#### § 185.700

shall be clearly marked in legible contrasting letters at least 12.7 millimeters (0.5 inches) high: "DISTRESS SIGNALS".

[CGD 85–080, 61 FR 1005, Jan. 10, 1996; 61 FR 24465, May 15, 1996]

## Subpart G—Operational Readiness, Maintenance, and Inspection of Lifesaving Equipment

#### §185.700 Operational readiness.

- (a) Each launching appliance and each survival craft and rescue boat on a vessel must be in good working order and ready for immediate use before the vessel leaves port and at all times when the vessel is underway.
- (b) Each deck where survival craft or rescue boats are stowed or boarded must be kept clear of obstructions that would interfere with the boarding and launching of the survival craft or rescue boat.

### §185.702 Maintenance.

- (a) The manufacturer's instructions for onboard maintenance of survival craft, rescue boats, and launching appliances, manufactured on or after March 11, 1996, must be onboard a vessel of more than 19.8 meters (65 feet) in length and readily available for a vessel of not more than 19.8 meters (65 feet) in length. The instructions must also be readily available at each inspection for certification and reinspection.
- (b) The owner or managing operator shall make sure that maintenance is carried out in accordance with the instructions required under paragraph (a) of this section.
- (c) The cognizant OCMI may accept, instead of the instructions required under paragraph (a) of this section, a shipboard planned maintenance program that includes the items listed in that paragraph.
- (d) The inspection and maintenance of the equipment listed in paragraph (a) of this section shall be logged or otherwise documented for review by the Coast Guard upon request.

#### §185.704 Maintenance of falls.

- (a) Each fall used in a launching appliance on a vessel must be turned end for end at intervals of not more than 30 months.
- (b) Each fall must be renewed when necessary due to deterioration or at intervals of not more than 5 years, whichever is earlier.
- (c) Each fall must have a corrosion resistant tag with the following permanently marked on it:
- (1) The date the new fall was installed; and
- (2) If the fall has been turned end for end, the date it was turned.

# §185.720 Weekly maintenance and inspections.

The following tests and inspections must be carried out weekly on a vessel:

- (a) Each survival craft, rescue boat, and launching appliance must be visually inspected to ensure its readiness for use:
- (b) Each rescue boat engine must be run ahead and astern for not less than 3 minutes, unless the ambient temperature is below the minimum temperature required for starting the engine; and
- (c) Each battery for rescue boat engine starting must be brought up to full charge at least once each week if:
- (1) The battery is of a type that requires recharging; and
- (2) The battery is not connected to a device that keeps it continuously charged.

## §185.722 Monthly inspections.

Each survival craft, rescue boat, and launching appliance on a vessel must be inspected monthly, using the manufacturers instructions to make sure it is complete and in good order.

## §185.724 Quarterly inspections.

- (a) Each winch control apparatus of a launching appliance on a vessel, including motor controllers, emergency switches, master switches, and limit switches, must be examined once in each 3 months.
- (b) The examination required by paragraph (a) of this section must include the removal of drain plugs and the opening of drain valves to make sure that enclosures are free of water.